

LIST OF COORDINATES FOR RVA YEREVAN TMA

Number Sector	Coordinate	Altitude/FL (In use -15°C and above) Altitude/FL (In use below -15°C)
1	40 01 45N 044 04 34E- 40 10 58N 044 02 29E- 40 09 50N 044 06 05E- 40 09 50N 044 26 45E- 40 08 03N 044 29 30E- 40 06 30N 044 28 02E- 39 57 31N 044 29 41E- then along state border with Turkey to 40 01 45N 044 04 34E	5100 5400
2	40 15 30N 043 40 37E- 40 15 30N 044 12 38E- 40 09 50N 044 12 38E- 40 09 50N 044 06 05E- 40 10 58N 044 02 29E- 40 01 45N 044 04 34E- then along state border with Turkey to 40 15 30N 043 40 37E	7000 7000
3	40 09 50N 044 12 38E- 40 15 00N 044 12 38E- 40 15 00N 044 21 21E- 40 14 09N 044 23 50E- 40 14 10N 044 27 30E- 40 13 30N 044 28 00E- 40 09 50N 044 26 45E- 40 09 50N 044 12 38E-	5700 6100
4	40 23 08N 043 36 35E- 40 23 08N 043 54 50E- 40 21 00N 043 56 37E- 40 15 30N 043 56 35E- 40 15 30N 043 40 37E- then along state border with Turkey to 40 23 08N 043 36 35E	9000 9000
5	40 23 08N 043 53 28E- 40 25 39N 043 59 01E- 40 21 00N 044 05 57E- 40 21 00N 043 56 37E- 40 23 08N 043 54 50E- 40 23 08N 043 53 28E-	FL130 FL140
6	40 21 00N 044 05 57E- 40 25 39N 043 59 01E- 40 31 30N 044 11 56E- 40 31 39N 044 22 00E- 40 27 14N 044 22 00E- 40 21 01N 044 14 28E 40 21 00N 044 05 57E	FL160 FL180
7	40 21 01N 044 14 28E- 40 27 14N 044 22 00E- 40 31 39N 044 22 00E- 40 32 03N 044 57 17E- 40 25 00N 044 57 40E- 40 25 00N 044 48 50E- 40 19 30N 044 46 32E- 40 23 02N 044 43 19E- 40 23 02N 044 36 44E- 40 21 00N 044 33 20E- 40 21 01N 044 14 28E	FL130 FL140
8	39 55 33N 044 31 26E- 39 59 25N 044 37 26E- 39 56 15N 044 40 00E-	7500 7500

	39 52 38N 044 40 38E- 39 50 03N 044 35 52E- then along state border with Turkey to 39 55 33N 044 31 26E	
9	40 15 30N 043 56 35E- 40 21 00N 043 56 37E- 40 21 00N 044 33 20E- 40 23 02N 044 36 44E- 40 23 02N 044 43 19E- 40 19 30N 044 46 32E- 40 14 32N 044 44 27E- 40 13 30N 044 32 38E- 40 13 30N 044 28 00E- 40 14 10N 044 27 30E- 40 14 09N 044 23 50E- 40 15 00N 044 21 21E- 40 15 00N 044 12 38E- 40 15 30N 044 12 38E- 40 15 30N 043 56 35E	10200 11100
10	40 14 32N 044 44 27E- 40 25 00N 044 48 50E- 40 25 00N 044 57 40E- 39 58 10N 044 59 06E- 40 00 00N 044 53 00E- 40 02 45N 044 48 30E- 40 14 32N 044 44 27E	FL140 FL160
11	40 05 30N 044 32 30E- 40 13 30N 044 32 38E- 40 14 32N 044 44 27E- 40 02 45N 044 48 30E- 39 52 38N 044 40 38E- 39 56 15N 044 40 00E- 40 05 30N 044 32 30E	9200 10000
12	39 57 31N 044 29 41E- 40 06 30N 044 28 02E- 40 08 03N 044 29 30E- 40 09 50N 044 26 45E- 40 13 30N 044 28 00E- 40 13 30N 044 32 38E- 40 05 30N 044 32 30E- 39 59 25N 044 37 26E- 39 55 33N 044 31 26E- 39 57 31N 044 29 41E	6300 6800
13	39 50 03N 044 35 52E- 39 52 38N 044 40 38E- 40 02 45N 044 48 30E- 40 00 00N 044 53 00E- 39 58 10N 044 59 06E- 39 56 50N 044 59 10E- 39 42 50N 044 46 12E- then along state border with Turkey to 39 50 03N 044 35 52E	FL130 FL130