

GEN 2.4 Location indicators

The location indicators marked with an asterisk (*) cannot be used in the address component of AFS messages.

1. ENCODE		2. DECODE	
<i>Location</i>	<i>Indicator</i>	<i>Indicator</i>	<i>Location</i>
YEREVAN / Zvartnots	UDYZ	UDDD	YEREVAN FIR
GYUMRI / Shirak	UDSG	UDSG	GYUMRI / Shirak
YEREVAN / Erebuni (MIL)	UDYE	UDYE	YEREVAN / Erebuni (MIL)
YEREVAN FIR	UDDD	UDYZ	YEREVAN / Zvartnots

PAGE INTENTIONALLY LEFT BLANK